

# WAYPOINT LIST (WGS84)

## TINHO ONE BRAVO RNAV DEPARTURE (RWY23L)

## TINHO ONE DELTA RNAV DEPARTURE (RWY23R)

Waypoint Name	Latitude	Longitude
TP230	250218.00N	1211018.00E
TP240	250136.00N	1211048.00E
DECOY	251218.00N	1210106.00E
OCTAN	252318.00N	1211654.00E
TINHO	242109.00N	1220143.00E

Seq No	Path Terminator	Fix Identifier (Waypoint Name)	Fly Over	Course °M (°T)	Turn Direction	Altitude (ft)	Speed Limit (kt)	Vertical Angle	Nav Performance
<b>TINHO ONE BRAVO RNAV DEPARTURE (RWY23L)</b>									
01	VA	-	-	234 (229.2)	-	+600	-210	-	RNAV 1
02	DF	TP240	Y	-	-	-	-210	-	RNAV 1
03	DF	DECOY	-	-	-	-	-	-	RNAV 1
04	TF	OCTAN	Y	057 (052.6)	-	-	-	-	RNAV 1
05	TF	TINHO	-	151 (146.8)	-	-	-	-	RNAV 1
<b>TINHO ONE DELTA RNAV DEPARTURE (RWY23R)</b>									
01	VA	-	-	234 (229.2)	-	+600	-210	-	RNAV 1
02	DF	TP230	Y	-	-	-	-210	-	RNAV 1
03	DF	DECOY	-	-	-	-	-	-	RNAV 1
04	TF	OCTAN	Y	057 (052.6)	-	-	-	-	RNAV 1
05	TF	TINHO	-	151 (146.8)	-	-	-	-	RNAV 1

Sector	DME Gap	Critical DME
<b>TINHO ONE BRAVO RNAV DEPARTURE (RWY23L)</b>		
RWY23L - TP240	Y	-
TP240 - DECOY	N	APU, HLG
DECOY - OCTAN	N	APU, HLG
OCTAN - TINHO	Y	-
<b>TINHO ONE DELTA RNAV DEPARTURE (RWY23R)</b>		
RWY23R - TP230	Y	-
TP230 - DECOY	N	APU, HLG
DECOY - OCTAN	N	APU, HLG
OCTAN - TINHO	Y	-

DME Gap: Y means gap EXIST, N means NO gap.